


Cross Section

Cross section shown intended to show flow paths only. Not representative of all valve configurations offered by Pneumadyne

Rely on Pneumadyne's fluid power expertise, design experience and manufacturing capabilities when developing your fluid handling applications



Solenoid 4-Way 5 Port 2 Position

Function

In the energized position, the spool is shifted to direct flow through port 1 and out port 4 as port 2 exhausts through port 3.

In the de-energized position, flow passes through port 1 and out port 2 as port 4 exhausts through port 5.